

**SETUP**

Turn Anticipation ..... SET-4  
 First Character ..... SET-5, 'K'  
 SUA Alert ..... SET-7  
 Altitude Alert ..... SET-9 (13)  
 Quicktune (94) ..... SET-14

**LOAD FLIGHT PLAN**

Chapter ..... FPL 1-25  
 Active Flight Plan ..... FPL-0

**CLEAR FLIGHT PLAN**

Chapter ..... FPL 0-25  
 Select ..... CLR

**LOAD SID/STAR**

Chapter ..... ACT-7 or APT-7

**MAP CONFIG (NAV-4)**

Map Config (89) ..... NAV-4,  
 ..... CRSR, MENU, ENT  
 Map Config (94) .... SET-7 or MNU  
 Line 4 (89) ..... NAV-4,  
 ..... CRSR Menu?, ENT  
 Line 4/5 (94) ..... NAV-4, CRSR

**ON COURSE HEADING**

Chapter ..... ACT-1 or APT-2

**RRR/DD POSITION**

Chapter ..... NAV-2

**CANCEL DIRECT TO**

Cancel ..... DTO, CLR, ENT  
 Flight Plan ..... Re-aligns if Active

**LOAD APPROACH**

Chapter ..... ACT-8 or APT-8  
 ..... (PROC)  
 Annunciator ..... GPS

**PROCEDURE TURN**

Approaching WP ..... OBS (OBS)  
 Outbound Course ..... SELECT  
 Course Reversal  
 Inbound Course ..... SELECT  
 Approaching FAF ..... OBS (LEG)

**RADAR VECTORS (89)**

Mode ..... OBS (OBS)  
 Waypoint Select ..... FAF  
 Course Select ..... INBOUND  
 Before FAF ..... OBS (LEG)

**RADAR VECTORS (94)**

On Load – IAF ..... VTF  
 On Vectors ..... PROC,  
 ..... ACTIVATE VECTORS

**DME ARC - Change Intercept**

Select ..... IAF (NAV-4 SCAN)  
 Select ..... CLR  
 MOVE? ..... ENT

**SEQUENCE TO MAHP**

Select ..... DTO

**NOTES**

User Waypoints – Delete from  
 AUX page.

**SETUP**

Select ..... NAV  
 Select ..... SYS  
 Select ..... NAV INFO/ENT  
 DIRECT TO ..... NEVER CLEAR  
 CDI SCALING ..... AUTO  
 Select ..... MAP  
 Select ..... MAP SETUP/ENT  
 ROUTE LINE ..... ON  
 MAP ORIENT ..... TRACK UP  
 MAP REF ..... PLANE  
 TRACK HISTORY ..... OFF

**LOAD FLIGHT PLAN**

Select ..... FPL  
 INNER KNOB ..... 1 LEFT  
 Select ..... SEL  
 Enter ..... Name/ENT  
 Load Waypoints  
 Complete ..... SEL

**CLEAR FLIGHT PLAN**

Select ..... FPL  
 INNER KNOWB ..... RIGHT  
 Select ..... SEL  
 INNER KNOB ..... 1 LEFT  
 Select ..... ENT

**LOAD APPROACH**

Select ..... NAV/MAP  
 Select ..... SEL  
 Load Approach? ..... ENT  
 Approach ..... SELECT

**PROCEDURE TURN**

Auto-Sequences or  
 Select ..... OBS/HOLD  
 Enter ..... INBOUND COURSE

**RADAR VECTORS**

Select ..... NAV/MAP  
 Select ..... SEL  
 Vectors to Final? ..... ENT

**DME ARC**

Auto-Sequences

**APPROACHING FAF**

Mode ..... OBS/HOLD (LEG)  
 External Annunciator ..... GPS

**SEQUENCE TO MAHP**

Select ..... D->

**ON COURSE HEADING**

Select ..... D->  
 Select ..... INFO

**RRR/DD POSITION**

Select ..... NRST  
 INNER KNOB ..... RIGHT